

AVIC-W8400NEX



## AVIC-W6400NEX

## Instructions: Apple CarPlay Set-up Via "Wireless" Connection

1. Power up the in dash receiver choose a display language and Output Mode.

2. Make sure your iPhone has Bluetooth and Wi-Fi switched on.

3. Plug your iPhone in through USB port 1. This is for the initial set up only.

4. On your iPhone answer the pop up question to Enable wireless CarPlay.

5. **Be patient.** This will take up to 1 minute the first time as connections and settings are made on the phone and on the in dash receiver.

6. Unplug the phone. You are now connected to CarPlay wireless.

